



**FUSE BLOCK DETAILS**  
**JUNCTION BLOCK**

TOP VIEW



BOTTOM VIEW



- 1 MAIN WIRING HARNESS CONNECTOR (C8)
- 2 TURN SIGNAL RELAY
- 3 SPARE FUSES
- 4 INSTRUMENT PANEL WIRING HARNESS CONNECTOR (C6)
- 5 FUSE LOCATIONS
- 6 IGNITION SWITCH CONNECTOR (C1)
- 7 IGNITION SWITCH CONNECTOR (C2)

- 8 GROUNDING BRACKET (G203)
- 9 COMBINATION SWITCH CONNECTOR (C4)
- 10 COMBINATION SWITCH CONNECTOR (C3)
- 11 INSTRUMENT PANEL WIRING HARNESS CONNECTOR (C5)
- 12 MAIN WIRING HARNESS CONNECTOR (C9)
- 13 MAIN WIRING HARNESS CONNECTOR (C7)
- 14 FLOOR WIRING HARNESS CONNECTOR (C10)

**FUSE BLOCK DETAILS**  
**FUSE BOXES**

